

Lovibond® Water Testing Tintometer® Group



Waste Water Set-Up MD 610

Waste water control with mobile data sets



- Mobile photometer MD 610
- Memory for 500 measurement results
- Data transmission via **Bluetooth®** and App AquaLX®
- Thermoreactor RD 125 with 24 tube holes

Part Number: 214110

Industry

Chemical Industry | Food and Beverage Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pharmaceutical Industry | Power and Energy

Application

Drinking Water Treatment | Galvanization | Raw Water Treatment | Waste Water Treatment

Waste Water Set-Up MD 610

You have to react immediately to the daily control routine - no matter where and when? With the mobile photometer MD 610, you can call up, evaluate and share the measurement results of the wastewater directly on site on your smartphone or tablet with your team. The interference filters ensure increased reproducibility of the results. With 120 pre-programmed methods and memory space for around 500 measured values, you are flexible in your routine work. With the RD 125 thermoreactor with 24 holes for 16 mm tubes, precisely fitting reagents for COD measurement and the appropriate accessories, you get the complete waste water set-up from a single source and save costs. **Note according to EU regulation 2019/1148**

This product contains restricted (acquisition, introduction, possession or use of this product by the general public is restricted by Regulation (EU) 2019/1148) as well as regulated explosives precursors as defined in Regulation (EU) 2019/1148. All suspicious transactions, and significant disappearances and thefts should be reported to the relevant national contact point. See https://ec.europa.eu/info/index_en

Measuring Range

Test Name	Measuring Range	Chemical Method
Ammonia HR TT	1.0 - 50 mg/l N	Salicylate
COD LMR TT	15 - 300 mg/l COD ^{b)}	Dichromate / H ₂ SO ₄
COD LR TT	3 - 150 mg/l COD ^{b)}	Dichromate / H ₂ SO ₄
COD MR TT	20 - 1500 mg/l COD ^{b)}	Dichromate / H ₂ SO ₄
Nitrate TT	1 - 30 mg/l N	Chromotropic Acid
Nitrite PP	0.01 - 0.3 mg/l N	Diazotation
Phosphate h. TT	0.02 - 1.6 mg/l P ^{b)}	Phosphomolybdenum Blue
TN HR TT	5 - 150 mg/l N ^{b)}	Persulphate Digestion

Technical Data

Portability Benchtop

Delivery Scope

- Photometer with standard accessories
- Thermo reactor RD 125
- COD tube tests 0 - 150 mg/l and 0 - 1500 mg/l
- Ammonia VARIO HR tube test 1 - 50 mg/l N
- Nitrate VARIO tube test 1 - 30 mg/l N
- Nitrite LR VARIO Powder Pack 0,01 - 0,3 mg/l N
- Nitrogen VARIO Total HR tube test 5 - 150 mg/l N
- Phosphate VARIO Total HR tube test 0.02 - 1 mg/l P / 0.06 - 3.5 mg/l PO₄
- Cuvette stand
- Membrane filter set
- Instruction manual
- Warranty information

Accessories

Title	Part Number
Round cuvette 24 mm, set of 12	197620
Round cuvette 24 mm, set of 5	197629
Round cuvette 16 mm, set of 10	197665
Adapter for round cuvettes 16 mm	19802190
Adapter for round cuvettes 13 mm	19802192
Thermoreactor RD 125	2418940
Membrane filter set for use when preparing samples, 25 membrane filters 0.45 µm, 2 syringes 20 ml	366150
Cuvette stand for 6 round cuvettes Ø 24 mm	418951
Cuvette stand for 10 round cuvettes Ø 16 mm	418957
Pipette tips*, 1-5 ml (white) 100 pc.	419066
Pipette tips**, 0,1-1 ml (white), 1000 pc.	419073
Automatic pipette*, 1-5 ml	419076
Automatic pipette**, 0,1-1 ml	419077
Plastic funnel with handle (white)	471007
W100/OG/10MM Rectangular cell, optical glass	601040
W100/OG/50MM Rectangular cell, optical glass	601070
W110/UV/10MM Rectangular cell, Quartz UV	661130

Tintometer GmbH
 Lovibond® Water Testing
 Schleefstraße 8-12
 44287 Dortmund
 Tel.: +49 (0)231/94510-0
 Fax: +49 (0)231/94510-30
 sales@lovibond.com
 www.lovibond.com
 Germany

The Tintometer Limited
 Lovibond House
 Sun Rise Way
 Amesbury, SP4 7GR
 Tel.: +44 (0)1980 664800
 Fax: +44 (0)1980 625412
 sales@lovibond.uk
 www.lovibond.com
 UK

Tintometer China
 Room 1001, China Life Tower
 16 Chaoyangmenwai Avenue,
 Beijing, 100020
 Tel.: +86 10 85251111 App. 330
 Fax: +86 10 85251001
 chinaoffice@tintometer.com
 www.lovibond.com
 China

Tintometer South East Asia
 Unit B-3-12, BBT One Boulevard,
 Lebuhr Nilam 2, Bandar Bukit Tinggi,
 Klang, 41200, Selangor D.E
 Tel.: +60 (0)3 3325 2285/6
 Fax: +60 (0)3 3325 2287
 lovibond.asia@tintometer.com
 www.lovibond.com
 Malaysia

Tintometer Brazil
 Caixa Postal: 271
 CEP: 13201-970
 Jundiaí – SP
 Tel.: +55 (11) 3230-6410
 sales@tintometer.com.br
 www.lovibond.com.br
 Brazil

Tintometer Inc.
 6456 Parkland Drive
 Sarasota, FL 34243
 Tel: 941.756.6410
 Fax: 941.727.9654
 sales@lovibond.us
 www.lovibond.com
 USA

Tintometer India Pvt. Ltd.
 Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
 Sanathnagar Industrial Estate,
 Hyderabad, 500018
 Telangana
 Tel: +91 (0) 40 23883300
 Toll Free: 1 800 599 3891/ 3892
 indiaoffice@tintometer.com
 www.lovibondwater.in
 India

Tintometer Spain
 Postbox: 24047
 08080 Barcelona
 Tel.: +34 661 606 770
 sales@tintometer.es
 www.lovibond.com
 Spain

Technical changes without notice
 Printed in Germany

Lovibond® and Tintometer® are Trademarks of the Tintometer Group of Companies